

KASSETTENFUSSBODEN

CASSETTE FLOORING

- 1 Aluprofilschiene
Alu profile rail
- 2 Rand-Profilschiene
Border - profile rail
- 3 Kassettenplatte
Cassette floor board
- 4 Ankerplatte
Base plate



Grundeinheit dieses Fußbodens ist eine Ankerplatte (4) aus verzinktem Stahl. An dieser Ankerplatte schließen senkrecht mittels Adapter die Hallenstütze und horizontal die Aluprofilschiene (1) sowie die Randprofilschiene (2) an. Die Trittfläche (3) besteht aus einer mehrschichtigen, wasserfest verleimten Siebdruckplatte und ist umlaufend mit einem Alu-Rahmenprofil eingefasst.

Die Tragfähigkeit beträgt 350 kg/m².

Größen: 2,90 m x 1,00 m | 4,90 m x 1,00 m
sowie schräge Platten für Sechs- und Achtecke

The basic element of this floor is a base plate (4) made of galvanised steel. Vertically attached to the base plate with the help of an adapter is the post of the hall and horizontally, there are the alu profile rail (1) and the border - profile rail (2). The tread consists of a multi-layered, water-proof glued screen printing plate; and it is bordered by an alu frame profile.

The load capacity is 350 kg/m².

Sizes: 2.90 m x 1.00 m | 4.90 m x 1.00 m
as well as diagonal cassette floor boards for hexagons and octagons